

s72 Fixing Instructions

(for areas already paved)

- 1 Determine the location for the bench. Remove pavers and excavate a hole L400 x W400 x D500mm. The size of the foundations may vary depending on the ground conditions. Foundations must be to Engineer's specification..
- 3 Place the bin into the hole and position at the correct height above ground level. Ensure the bin is plumb then prop securely.
- 4 Back fill holes with concrete (35N20) leaving sufficient depth for paving slabs and bedding.
- 5 Once set remove props.
- 6 Where necessary cut the paving slabs and reinstate ensuring that they are well bedded in.
- 7 Render neatly around leg tubes with non shrink grout, removing any grout residue.

