


S23 114 sq socket box installation

Foundations

Foundations must be to engineers specification. Omos recommends a minimum cube size of 400mm.

- 1 Set out the position of the bollard/s.
- 2 Where the area has been paved remove sufficient paviors to facilitate excavation.
- 3 Excavate holes to engineer's specification.
- 4 Position socket box precisely ensuring correct position and height (top of socket box should be flush with finished paving level). The bollard may be inserted to check plumb then carefully removed.
- 5 Back fill holes with concrete (35N20) leaving sufficient depth for paving slabs and bedding.
- 7 Where necessary cut the paving slabs and reinstate.
- 8 Render neatly around socket box with non shrink grout, removing any grout residue.



product code
s23

UNLESS OTHERWISE SPECIFIED, DIMENSIONS ARE IN MM, **DETAILS AND DIMENSIONS SUBJECT TO CHANGE WITHOUT NOTICE**

SOLIDWORKS DRAWING
DO NOT MANUALLY UPDATE

3RD ANGLE PROJECTION

DRG. NO. 23021001.1

SHEET SIZE A4

ISSUE NO. 1

DATE 23.02.10

omos

U1 Military Rd. Ind. Park, Newbridge Rd., Naas, Co. Kildare, Ireland
t + 353 45 899802 f + 353 45 899803 e design@omos.ie